

Manufacturer	Locomotive/Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement	Made In
Life-Like	Steam		0-6-0 Saddle Tank Switcher	Life-Like	Body: front and rear	1135 (001 42 000)			China
Life-Like	Steam		0-6-0 Side Tank Switcher #147	Life-Like	Body: front and rear	1113 (001 30 005)			Yugoslavia
Life-Like	Steam		2-8-4	Life-Like	Pilot and Tender	1015 (001 02 000)/1016 (001 02 006)	Will need to shim pilot coupler .010		
Life-Like	Steam		2-8-8-2	Life-Like	Tender and Pilot	1015 (001 02 000)/1016 (001 02 006)	Need shim between coupler and coupler cradle on tender. Measure fit, second shim may be necessary. 1016 (001 02 006) necessary for clearance over pilot.		
Life-Like	Diesel	EMD	BL-2	Life-Like	1135 (001 42 000)	1163 (001 421 010) (MTL pilot: front & rear; aluminum, blue, yellow)			China
Life-Like	Diesel	EMD	C-Liner A unit	Life-Like		1015 (001 02 000)/1016 (001 02 006) w/shim	Front: use screw, rear use clip		
Life-Like	Diesel	EMD	C-Liner B unit	Life-Like		1015 (001 02 000)/1016 (001 02 006) w/shim	Front and rear use clip		
Life-Like	Diesel	EMD	E-6A	Life-Like	Rear: 1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)	Pilot: 1021 (001 02 021)			China
Life-Like	Diesel	EMD	E-6B	Life-Like	1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)				China
Life-Like	Diesel	EMD	E-7A	Life-Like	Rear: 1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)	Pilot: 1021 (001 02 021)			China
Life-Like		EMD	E-7B	Life-Like	1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)				China
Life-Like	Diesel	EMD	E-8 E9 7800 series	Life-Like		1015 (001 02 000)/1016 (001 02 006)	Add .010 shim under coupler to lift to right height. Replace pilot pin with 0090-1/4 screw.		
Life-Like	Diesel	EMD	E-8	Life-Like	Rear: 1129 (001 30 013)	Pilot: 1021 (001 02 021)			China
Life-Like	Diesel	Alco	PA-1	Life-Like	Rear: 1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)	Pilot: 1021 (001 02 021)			China
Life-Like	Diesel	Alco	PB-1	Life-Like	1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)				China
Life-Like	Diesel	Alco	FA-1 (2000 Release)	Life-Like		1015 (001 02 000)/1016 (001 02 006) both ends			China
Life-Like	Diesel	Alco	FB-1 (2000 Release)	Life-Like		1015 (001 02 000)/1016 (001 02 006) both ends			China
Life-Like	Diesel	Alco	FA-2 and FB-2 2002 Release	Life-Like		1015 (001 02 000)/1016 (001 02 006) both ends			China
Life-Like	Diesel	Alco	C-424	Life-Like		1015 (001 02 000)/1016 (001 02 006) both ends			China
Life-Like	Diesel	Alco	Erie Build A and B	Life-Like		1015 (001 02 000)/1016 (001 02 006) both ends			China
Life-Like	Diesel	EMD	FA-2	Life-Like		1165 (001 421 020) (MTL pilot: front & rear)			China
Life-Like	Diesel	EMD	FB-2	Life-Like		1016 (001 02 006)			China
Life-Like	Diesel	EMD	F-7 (w/ pre-1995 Blomberg truck sideframes)	Life-Like	1135 (001 42 000)				China
Life-Like	Diesel	EMD	F-7 (w/ post-1995 Blomberg truck sideframes)	Life-Like	1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)				China
Life-Like	Diesel	EMD	F-40 PH (w/ pre-1995 Blomberg truck sideframes)	Life-Like	1135 (001 42 000)				China
Life-Like	Diesel	EMD	GP-9 (Canada Production)	Life-Like	1015 (001 02 000)/1016 (001 02 006)				China
Life-Like	Diesel		DI-109	Life-Like	1015				
Life-Like	Diesel	EMD	Alco C 424 (Canada Production)	Life-Like	1015 (001 02 000)/1017 (003 41 051)				
Life-Like	Diesel	EMD	F-40 PH (w/ post-1995 Blomberg truck sideframes)	Life-Like	1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)				China
Life-Like	Diesel	EMD	GP-18 (w/ pre-1995 Blomberg truck sideframes)	Life-Like	1135 (001 42 000)	1166 (001 421 030) (MTL pilot: front & rear)			China
Life-Like	Diesel	EMD	GP-18 (w/ post-1995 Blomberg truck sideframes)	Life-Like	1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)	1166 (001 421 030) (MTL pilot: front & rear)			China
Life-Like	Diesel	EMD	GP-18 2004 (001 02 052) Release	Life-Like		1015 (001 02 000)/1016 (001 02 006)			
Life-Like	Diesel	EMD	GP-20 (1999 release)	Life-Like		1015 (001 02 000)/1016 (001 02 006)			China
Life-Like	Diesel	EMD	GP-38 (w/ pre-1995 Blomberg truck side frames)	Life-Like	1135 (001 42 000)				China
Life-Like	Diesel	EMD	GP-38 (w/ post-1995 Blomberg truck side frames)	Life-Like	1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)				China
Life-Like	Diesel	EMD	GP-40	Life-Like	1110				Yugoslavia
Life-Like	Diesel	EMD	SD-7	Life-Like		1015 (001 02 000)			China
Life-Like	Diesel	EMD	SD-9	Life-Like		1015 (001 02 000)/1016 (001 02 006)			China
Life-Like	Diesel	EMD	SD-45	Life-Like	1109 (001 30 008), 1128 (001 30 012)				Yugoslavia
Life-Like	Diesel	EMD	GP-60	Life-Like		1015 (001 02 000)/1016 (001 02 006)			China
Life-Like	Diesel	EMD	SW-9/1200 (also any SW-Combination .8-9-12)	Life-Like		1015 (001 02 000)/1016 (001 02 006)			China
Life-Like	Diesel	(note)	Diesels with Blomberg style trucks released before 1995 having truck mounted couplers (F-7, F40-PH, GP-18, GP-38, etc.)		1135 (001 42 000)				China
Life-Like	Diesel	(note)	Diesels with Blomberg style trucks released early 1995 and onward having truck mounted couplers (F-7, F40-PH, GP-18, GP-38, etc.)	Life-Like	1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)				China
Life-Like	Rolling Stock		North Eastern Caboose		1128 (001 30 012), 1129 (001 30 013)			1000 (003 01 021)	
Life-Like	Rolling Stock		Caboose (#7710)			1135 (001 42 000)			

Manufacturer	Locomotive/Car	Make	Description	OEM	Truck Conversion	Body Mount Conversion	Conversion Notes	Truck Replacement	Made In
Life-Like	Cars		Passenger or Freight Cars, body mount				body mount (refer to the body mount applications section in the conversion guide for		
Lima	Diesel	EMD	F-7A (w/ split 1 pc. draft gear box)	Lima	1129 (001 30 013), 1130 (001 30 014)				Italy
Lima	Diesel	EMD	F-7A (w/ metal draft gear box clip)	Lima	1129 (001 30 013)				Italy
Lima	Diesel	Plymouth	MDT Diesel Switcher	Lima		1128 (001 30 012)			Italy
Lima	Diesel	EMD	GP-30	Lima		1128 (001 30 012), 1129 (001 30 013)			Italy
Lima	Diesel	EMD	FP-45 (w/ metal draft gear box clip)	Lima	1114 (001 30 006)				Italy
Lima	Cars		Passenger or Freight Cars (w/ split 1 pc. draft gear box)		1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)				
Lima	Cars		Passenger or Freight Cars (w/ metal draft gear box clip)		1104 (001 30 009) (001 30 009), 1128 (001 30 012), 1129 (001 30 013), 1130 (001 30 014)				
Lima	Cars		Freight truck (w/ mounted MTL coupler assy)					1000 (003 01 021), 1002 (003 01 024), 1003 (003 01 022), 1010 (001 30 004) (003 01 001), 1030 (003 01 031), 1012 (003 01 004), 1030 (003 01 031), 1032 (003 01 034), 1035 (003 01 041), 1037 (003 01 042), 1038 (003 01 044)	
Lima	Cars		Passenger truck (w/ mounted MTL coupler assy)					1017 (003 41 051), 1018 (003 41 061)	
Lima	Cars		Passenger or Freight Cars, body mount				body mount (refer to the body mount applications section in the conversion guide for		